OEL Recommended Spare Parts List

OKIFAX 4580/OKIOFFICE 86

Revision 7

Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Del/ Add	ks for environment
					per 500	per 1000	per 2000			
CABINET ASSEMBLY(FX-046VP)	3	4YA4116-1228G001	LED HEAD GENERAL SPEC. 31B	1	1	2	4			G
CABINET ASSEMBLY(FX-046VP)	4a	41016104	Cable-Flat-Assy	1	5	10	20			G
CABINET ASSEMBLY(FX-046VP)	8b	40588901	DC POWER SUPPLY UNIT(230V)	1	5	10	20			G
CABINET ASSEMBLY(FX-046VP)	9	41999401	Board-V46	1	3	6	12			G
CABINET ASSEMBLY(FX-046VP)	10a	42310701	Board- EN2	1	3	6	12	OEL (Europe)		G
CABINET ASSEMBLY(FX-046VP)	10c	41172901	Board-G4N	1	3	6	12	ISDN (Option)		X
CABINET ASSEMBLY(FX-046VP)	10f	41143905	Board-INU	1	3	6	12	NO-EC (East Europe)		G
CABINET ASSEMBLY(FX-046VP)	11	40605601	H.V. Board P6L	1	5	10	20			G
CABINET ASSEMBLY(FX-046VP)	13	40672901	Plate Assy.-Base(A)	1	3	6	12			G
CABINET ASSEMBLY(FX-046VP)	14b	42422901	Plate Assy.-Package	1	3	6	12	OEL		G
CABINET ASSEMBLY(FX-046VP)	15	40236401	Plate Assy.-Shield(HV)	1	3	6	12			G
CABINET ASSEMBLY(FX-046VP)	17	41767002	Frame Assy.-Scanner L	1	3	6	12	300dpi		G
CABINET ASSEMBLY(FX-046VP)	18	41766704	Frame Assy.-Scanner(U)	1	3	6	12			G
CABINET ASSEMBLY(FX-046VP)	21	40606501	Cover-Main(A)	1	3	6	12			-
CABINET ASSEMBLY(FX-046VP)	22	40025301	Cover-Front	1	3	6	12			-
CABINET ASSEMBLY(FX-046VP)	24	42282201	Cover-Rear	1	3	6	12			-
CABINET ASSEMBLY(FX-046VP)	25	40672801	Cover Assy.-Top(A)	1	3	6	12			G
CABINET ASSEMBLY(FX-046VP)	26	40026101	Spring-TC	1	3	6	12			-
CABINET ASSEMBLY(FX-046VP)	27	40024001	Guide-Paper(U)	1	3	6	12			-
CABINET ASSEMBLY(FX-046VP)	28	4PP4083-6168P001	HEAD SPRING	2	3	6	12			-
CABINET ASSEMBLY(FX-046VP)	29	40024101	Guide-Paper(L)	1	3	6	12			-
CABINET ASSEMBLY(FX-046VP)	36	40773601	Sheet-Shield(LED)	1	3	6	12			-
CABINET ASSEMBLY(FX-046VP)	39	40140801	Bracket-Damper	1	3	6	12			G
CABINET ASSEMBLY(FX-046VP)	40	42596601	Damper-Oil	1	3	6	12			-
CABINET ASSEMBLY(FX-046VP)	41	40025701	Tray-Document	1	3	6	12			-
CABINET ASSEMBLY(FX-046VP)	42	40025801	Tray-Paper	1	3	6	12			-
CABINET ASSEMBLY(FX-046VP)	43	40375801	Stacker Assy.-Document	1	3	6	12			-
CABINET ASSEMBLY(FX-046VP)	51	223A7010P0003	TM-6-DC1	1	3	6	12	GER, TENOVIS		-
CABINET ASSEMBLY(FX-046VP)	55	41345101	Cap-TEL_IF	1	3	6	12			-
UNIT-PRINTER	5	40607401	H.V. Board P2H	1	5	10	20			G
UNIT-PRINTER	6	40413401	Cover-HV	1	3	6	12			-
OPE PANEL	1	41766905	OP Panel Assy.-Partial	1	3	6	12	ODA/OEL/INT/AUS It include Item : 40040001 Connection Cord-Wire(OPE).		G
OPE PANEL	4	40023601	Sheet-Cover	1	5	10	20			-
OEP PANEL ASSEMBLY	2	43415401	Board-P4F	1	3	6	12			-
OEP PANEL ASSEMBLY	4	40023101	Button-Function	4	6	12	24			-
OEP PANEL ASSEMBLY	5	2PP4120-1067P001	TEN KEY	1	3	6	12			-

Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Del/ Add	ks for environment
					per 500	per 1000	per 2000			
OEP PANEL ASSEMBLY	6	40023206	Button-Start	1	3	6	12	OKI		-
OEP PANEL ASSEMBLY	7	40023306	Button-Stop	1	3	6	12	OKI		-
OEP PANEL ASSEMBLY	9	43417001	FX046-Display-LCD	1	3	6	12			-
FRAME ASSEMBLY-SCANNER L	2	40019401	Lever-PC1	1	3	6	12			-
FRAME ASSEMBLY-SCANNER L	3	40019501	Lever-PC2	1	3	6	12			-
FRAME ASSEMBLY-SCANNER L	4	40019601	Roller Assy.-ADF	1	3	6	12			G
FRAME ASSEMBLY-SCANNER L	5	40020201	Plate-Earth ADF	1	3	6	12			-
FRAME ASSEMBLY-SCANNER L	6	40020601	Piece-Exit	2	6	12	24			-
FRAME ASSEMBLY-SCANNER L	7	40020703	Spring-Exit	2	6	12	24			-
FRAME ASSEMBLY-SCANNER L	8	40127501	CONN Cord-Speaker	1	3	6	12			G
FRAME ASSEMBLY-SCANNER L	9	40141401	Contact Image Sensor	1	3	6	12	300dpi		G
FRAME ASSEMBLY-SCANNER L	10	40644701	Film-Guide(CIS)	2	3	6	12			-
FRAME ASSEMBLY-SCANNER L	14	40020301	Gear-Z95/14	1	3	6	12			-
FRAME ASSEMBLY-SCANNER L	15	40020501	Spring-Latch	2	6	12	24			-
FRAME ASSEMBLY-SCANNER L	18	40153801	Spring-Reinforcement	1	3	6	12			-
FRAME ASSEMBLY-SCANNER L	19	40025201	Gear-Z38	1	3	6	12			-
FRAME ASSEMBLY-SCANNER L	20	40024501	Spring-CIS	1	3	6	12			-
FRAME ASSEMBLY-SCANNER L	21	41667901	Plate-Earth_CIS	1	3	6	12			-
FRAME ASSEMBLY-SCANNER L	22	41734401	Foam-Shielding	2	6	12	24			-
FRAME ASSEMBLY-SCANNER L	23	40899901	Spring-Reinforcement_add_work	1	3	6	12			-
PLATE ASSEMBLY-SCANNER(B)	3	40135301	Photo-Interrupter	2	6	12	24			G
PLATE ASSEMBLY-SCANNER(R)	2	4YB4120-1036P001	S MOTOR-151/175	1	3	6	12			G
FRAME ASSEMBLY-SCANNER(U)	2	4PP3527-5153P001	BACK-UP PLATE	1	3	6	12			-
FRAME ASSEMBLY-SCANNER(U)	3	40267001	Separator Assy.-ADF	1	5	10	20			-
FRAME ASSEMBLY-SCANNER(U)	5	40021401	Spring-Pinch(L)	1	3	6	12			-
FRAME ASSEMBLY-SCANNER(U)	6	40021501	Spring-Pinch(R)	1	3	6	12			-
FRAME ASSEMBLY-SCANNER(U)	7	40745802	Guide-Sensor(A)	1	3	6	12			-
FRAME ASSEMBLY-SCANNER(U)	8	40021702	Guide-Sensor(B)	2	6	12	24			-
FRAME ASSEMBLY-SCANNER(U)	9	40481101	Spring-ADF(048)	1	3	6	12			-
FRAME ASSEMBLY-SCANNER(U)	10	40199101	Cord-Earth	1	3	6	12			-
FRAME ASSEMBLY-SCANNER(U)	12	40021202	Roller Assy.-Sensor	1	6	10	20			G
FRAME ASSEMBLY-SCANNER(U)	13	40022001	Bearing-S	1	3	6	12			-
FRAME ASSEMBLY-SCANNER(U)	14	40020801	Gear-Z31	1	3	6	12			-
FRAME ASSEMBLY-SCANNER(U)	16	40026301	Bar-Discharge	1	3	6	12			-
FRAME ASSEMBLY-SCANNER(U)	17	40461301	Film-Exit(DOC)	1	3	6	12			-
FRAME ASSEMBLY-SCANNER(U)	19	1051002C0001	TR-13-7-6	1	3	6	12			G

Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Del/ Add	ks for environment
					per 500	per 1000	per 2000			
FRAME ASSEMBLY-SCANNER(U)	20	41592101	Tape-Insulation	1	3	6	12	L=200mm		-
COVER ASSEMBLY-TOP	2	40606701	Holder-LED(A)	1	3	6	12			-
COVER ASSEMBLY-TOP	5	40022601	Spring-D	1	3	6	12			-
COVER ASSEMBLY-TOP	6	4PP4128-1268P001	PLATE EXIT	2	6	12	24			-
COVER ASSEMBLY-TOP	7	4PP4083-2024P001	EJECT ROLLER A	2	6	12	24			-
COVER ASSEMBLY-TOP	8	4PP4083-2328P003	PINION GEAR B	1	3	6	12			-
PLATE ASSEMBLY-BASE	3	40606901	Sheet-Insulation(A)	1	3	6	12			-
PLATE ASSEMBLY-BASE	4	40128001	Cord-Flat(FUJI CARD)	1	5	10	20			G
PRINTER BASE FRAME UNIT	1	40593201	Frame Unit Assy	1	3	6	12			-
PRINTER BASE FRAME UNIT	3	3PP4083-1191P001	SENSOR PAPER E	2	6	12	24			-
PRINTER BASE FRAME UNIT	4	40721301	Separator Assy	1	3	6	12			-
PRINTER BASE FRAME UNIT	6	40781701	Spring Compression S	1	3	6	12			-
PRINTER BASE FRAME UNIT	7	3PA4083-1193G001	SENSOR ASSY TONER	1	3	6	12			G
PRINTER BASE FRAME UNIT	8	40496401	Motor-Pulse	1	3	6	12			G
PRINTER BASE FRAME UNIT	11	40779601	Roller Hopping	1	3	6	12			-
PRINTER BASE FRAME UNIT	12	3PP4083-1128P001	HOLDER ROLLER H	1	3	6	12			-
PRINTER BASE FRAME UNIT	13	3PB4083-1127P001	MAGNET H.	1	3	6	12			G
PRINTER BASE FRAME UNIT	14	3PA4083-1133G001	SHAFT HOPPING ASSY	1	3	6	12			G
PRINTER BASE FRAME UNIT	15	NK2-10-SUS	KNOCK PIN	1	3	6	12			-
PRINTER BASE FRAME UNIT	16	4PP4083-1143P001	GEAR IDLE R	1	3	6	12			-
PRINTER BASE FRAME UNIT	17	3PP4083-1184P001	IDLE GEAR 2R	1	3	6	12			-
PRINTER BASE FRAME UNIT	18	3PP4083-1142P001	GEAR R	1	3	6	12			-
PRINTER BASE FRAME UNIT	19	2PP4083-1181P001	GEAR IDLE M	1	3	6	12			-
PRINTER BASE FRAME UNIT	20	3PP4083-1189P001	PLATE EARTH A	1	3	6	12			-
PRINTER BASE FRAME UNIT	21	3PP4083-1188P001	PLATE SIDE M	1	3	6	12			G
PRINTER BASE FRAME UNIT	22	3PP4083-1182P001	GEAR IDLE P	2	6	12	24			-
PRINTER BASE FRAME UNIT	23	40721001	Gear-Idle-3R	1	3	6	12			-
PRINTER BASE FRAME UNIT	24	4PP4083-1165P001	PLATE TENSION	1	3	6	12			-
PRINTER BASE FRAME UNIT	25	3PP4083-1185P001	GEAR IDLE HEAT	1	3	6	12			-
PRINTER BASE FRAME UNIT	26	4PP4083-1186P001	GEAR IDLE EA	1	3	6	12			-
PRINTER BASE FRAME UNIT	27	3PP4083-1187P001	GEAR IDLE EB	1	3	6	12			-
PRINTER BASE FRAME UNIT	28	3PP4083-1170P001	SHAFT DRIVE E	1	3	6	12			-
PRINTER BASE FRAME UNIT	29	40074601	Roller Eject	2	6	12	24			-
PRINTER BASE FRAME UNIT	30	3PP4083-1141P001	BEARING REGIST	4	14	28	56	ECO-OP8-068		-
PRINTER BASE FRAME UNIT	31	3PB4083-1140P001	ROLLER REGIST	1	3	6	12			G
PRINTER BASE FRAME UNIT	32	41802101	Film-Guide_F	1	3	6	12			-
PRINTER BASE FRAME UNIT	33	40737801	Gear-T	1	3	6	12			-

Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Del/ Add	ks for environment
					per 500	per 1000	per 2000			
PRINTER BASE FRAME UNIT	34	40713601	Roller-Transfer	1	3	6	12			G
PRINTER BASE FRAME UNIT	35	4PP4083-1136P001	SPRING PRESSURE L	1	3	6	12			-
PRINTER BASE FRAME UNIT	36	3PP4083-1161P001	BEARING BU	2	6	12	24			-
PRINTER BASE FRAME UNIT	37	40594601	Roller Pressure B	1	3	6	12			G
PRINTER BASE FRAME UNIT	38	3PP4083-1233P001	GUIDE PAPER R	1	3	6	12			-
PRINTER BASE FRAME UNIT	39	3PP4083-1232P001	GUIDE PAPER L	1	3	6	12			-
PRINTER BASE FRAME UNIT	40	1PP4083-1231P001	HOLDER PAPER	1	3	6	12			-
PRINTER BASE FRAME UNIT	41	3PP4083-1192P001	SENSOR PAPER EXIT	1	3	6	12			-
PRINTER BASE FRAME UNIT	42	41802001	Spring-Hopper_F	1	3	6	12			-
PRINTER BASE FRAME UNIT	43	40638001	Contact-CB	1	3	6	12			-
PRINTER BASE FRAME UNIT	44	40638102	CONN Cord-HV	1	3	6	12			G
PRINTER BASE FRAME UNIT	46	40625401	Fan	1	3	6	12			-
PRINTER BASE FRAME UNIT	47	4PP4083-1137P001	SPRING PRESSURE R	1	3	6	12			-
PRINTER BASE FRAME UNIT	49	40562401	Guide Sheet	1	3	6	12			-
PRINTER BASE FRAME UNIT	51b	41982502	Heat Assy	1	5	10	20	230V DCO-SQ1-1709		G
PRINTER BASE FRAME UNIT	52	40034001	SPRING STOPPER	1	3	6	12			-
PRINTER BASE FRAME UNIT	54	40688601	Washer-TR	1	3	6	12			-
PRINTER BASE FRAME UNIT	55	40710301	Guide-Gear T	1	3	6	12			-
PRINTER BASE FRAME UNIT	56	40634701	Bearing-Gear	1	3	6	12			-
PRINTER BASE FRAME UNIT	56	42889301	Bearing-Gear-Idle-3R	1	3	6	12	ECO-OP8-068		-
PRINTER BASE FRAME UNIT	57	LP-6401-B1	TYING CORD	1	3	6	12			-
PRINTER HEAT ASSY.	1	3PB4083-1202P001	ROLLER HEAT	1	5	10	20			-
PRINTER HEAT ASSY.	2b	41524002	Lamp-Halogen	1	5	10	20	230V		G
PRINTER HEAT ASSY.	3	4PB4083-1204P001	THERMOSTAT	1	5	10	20			G
PRINTER HEAT ASSY.	4	42106801	Thermistor	1	5	10	20			G
PRINTER HEAT ASSY.	5	4PB4083-1213P001	CORD HEAT	1	5	10	20			G
CABLES	1	40635401	CONN Cord-Wire(AC)	1	3	6	12			G
CABLES	2	40040001	CONN Cord-Wire(OPE)	1	3	6	12			G
CABLES	3	40040201	CONN Cord-Wire(CIS)	1	3	6	12			G
CABLES	4	40040301	CONN Cord-Wire(PC1/2)	1	3	6	12			G
CABLES	5	105A1070C0003	TFC-20-10-10	1	3	6	12	CIS-V46		G
CABLES	6	105A1070C0004	TFC-23-11-14	1	3	6	12	CPE-V46		G
CABLES	7	105A1073C4002	SSC-40-12	1	3	6	12	HV-V46		G
CABLES	9	1051003C0001	FPC-25-20	1	3	6	12	LED-V46		G
CABLES	14a	1051007C0001	SFT-59SN	1	3	6	12	For LINE Cord use		G
CABLES	14b	105A1062C0002	0443-167251	1	3	6	12	For G4 Cord use		X
CABLES	15	40687701	Cord-Flat (SUMI CARD)	1	3	6	12	P6L-V46		G